



**ADVANCED**  
NETWORK DEVICES

## Dynamic Background Images with InformaCast

Version 1.0

2/11/2025

© 2025 ADVANCED NETWORK DEVICES

3820 NORTH VENTURA DR.

ARLINGTON HEIGHTS, IL 60004

U.S.A

ALL RIGHTS RESERVED

## PROPRIETARY NOTICE AND LIABILITY DISCLAIMER

The information disclosed in this document, including all designs and related materials, is the valuable property of Digital Advanced Network Devices and/or its licensors. Advanced Network Devices and/or its licensors, as appropriate, reserve all patent, copyright and other proprietary rights to this document, including all design, manufacturing, reproduction, use, and sales rights thereto, except to the extent said rights are expressly granted to others.

The Advanced Network Devices product(s) discussed in this document are warranted in accordance with the terms of the Warranty Statement accompanying each product. However, actual performance of each product is dependent upon factors such as system configuration, customer data, and operator control. Since implementation by customers of each product may vary, the suitability of specific product configurations and applications must be determined by the customer and is not warranted by Advanced Network Devices.

To allow for design and specification improvements, the information in this document is subject to change at any time, without notice. Reproduction of this document or portions thereof without prior written approval of Advanced Network Devices is prohibited.

## TROUBLESHOOTING AND ADDITIONAL RESOURCES


Support Site:	<a href="https://www.anetd.com/user-support/">https://www.anetd.com/user-support/</a>
Technical Resources:	<a href="https://www.anetd.com/user-support/technical-resources/">https://www.anetd.com/user-support/technical-resources/</a>
AND Legal Disclaimer:	<a href="https://www.anetd.com/legal">https://www.anetd.com/legal</a>

## OVERVIEW

Dynamic background images can be hosted from an InformaCast server to be displayed on AND devices as a part of a notification. The screen resolution for the HD display is 1920 x 720. Images smaller than this resolution will be centered, and images larger than the supported resolution will be cropped. For the best viewing experience, we recommend images to be resized to fit the display perfectly. The supported file types are currently .gif, .tga, .png, .bmp, .jpg. This app note walks through the two methods for using dynamic images, Inline Text Message Markup and Notification Profile Icons.

## UPLOADING THE IMAGE

- 1.) Using an FTP Client such as WinSCP, login to the InformaCast Fusion server with valid credentials:



2.) Navigate to the following directory:

“/data/d\_{version\_number}/usr/local/singlewire/InformaCast/web/resources”.


To keep the /resources directory organized, an image folder can be created within this directory. However, this is optional and an image can be placed in the resources directory. Upload the desired image(s) to the chosen directory.

/data/d_14.29.2_64/usr/local/singlewire/InformaCast/web/resources/Images/				
Name	Size	Changed	Rights	Owner
..		3/18/2025 1:56:40 PM	rw-rw-rw-	admin
example.png	214 KB	6/26/2024 10:30:42 AM	rw-r--r--	admin

## INLINE TEXT MESSAGE MARKUP

Inline Text Message Markup requires the image to be uploaded to the InformaCast server. Please refer to the above instructions to upload images to an InformaCast server.

1.) Login to the InformaCast web dashboard and navigate to **Message Templates**.



The screenshot shows the InformaCast web dashboard. On the left sidebar, the 'Message Templates' option is highlighted with a red box. The main content area is titled 'List Message Templates' and includes a search bar with the text 'example'. Below the search bar are several filter buttons: 'Image', 'Audio', 'Confirmation Request', 'Incident Plan', 'Managing Site', and 'Shared Status'. The table below lists three message templates:

Name	Details	Site Access
Example InformaCast Fusion Alert	TESTING: This is an InformaCast ...	Global
Inline Color Example	{color=ochre}This text will be o...	Global
Inline Text Color Command Example	{color=red,bgcolor=black}Display...	Global

At the bottom right of the table, there is a 'Show 25' dropdown and pagination controls '1-3 of 3'.

- 2.) Create and configure the message template with a *Name*, *Subject*, and a *Body*. To display an image as part of this notification, we will need to enter the following inline text message variable into the *Body* of the message template, where “{server\_IP}” is the IP address of the InformaCast server:

```
{image1=http://{server_IP}:8081/InformaCast/resources/images/redlock.jpg}
```

Below is an example of how this would look:

### Notification Profile Settings (Optional)

Assign a notification profile to your message template—setting delivery, content, and layout preferences—and optionally customize its settings in place.

#### Content

Define the content to include in your message template, e.g. text, audio, image, confirmation response, incident plan, etc.

**Name**


**Subject**


  
Immediately visible on most notification recipients, Subject text is a summary of your notification.  
[Insert Variables](#)


**Body**


  
Not always immediately visible, Body text provides more details about your notification and requires user interaction, e.g. opening a notification.  
[Insert Variables](#)


Which types of content would you like to include in your message template?

  
Audio

  
Image


  
Confirmation Request

  
Incident Plan



Advanced Network Devices • 3820 Ventura Dr. Arlington Hts. IL 60004  
Support: [tech@anetd.com](mailto:tech@anetd.com) • 847-463-2237 • [www.anetd.com](http://www.anetd.com)


5



v1.0

## NOTIFICATION PROFILE ICON

- 1.) Navigate to **Notification Profiles** under the *Notifications* menu and select **Create Notification Profile**.
- 2.) Enter a unique profile name for the Notification Profile. In this example, the “Example Test” Notification Profile is being created.
- 3.) The Notification Profile *Message Type* must contain Text to add an image. To set the *Message Type*, navigate to *On-premises Server* and enable the *Use Custom On-Premises Server Settings* slider.



**Notification Profile Settings**  
Use your default notification profile or select a new one, and optionally customize its settings in place.


Global Overrides   Color and Display   **On-premises Server**   Outbound CAP

Use Custom On-premises Server Settings ☒

**General Settings**  
Disable sending notifications to on-premises recipients or set your preferences for the type of audio and/or text that will be sent to on-premises recipients.

**Message Type**  
Text and Pre-Recorded Audio

- 4.) In the Icon area, select *Choose File* to select an image from your local machine. Note: Enabling the *Concatenate Text* option will cause the *Icon* setting to disappear. The *Icon* will still be saved and used.



**Text Settings**  
Define the display settings for notification text sent to on-premises recipients.

**Persistent Text**  
Notification text will remain indefinitely on the display of Cisco IP phones for Unified CM. ☐

**Concatenate Text**  
A notification's Subject and Body contents will be displayed together instead of viewed separately. ☐

**Scroll Type**  
Repetitions

**Scroll Repetitions**

**Scroll Speed**  
5

**Icon**

Image files can be JPG, PNG, or GIF, and must be less than 5MB and 5120x5120. Icons display next to a notification's Subject contents on supported devices.

- 5.) In the Message Template that is going to use this image, select the created Notification Profile to use:

**Notification Profile Settings (Optional)**  
Assign a notification profile to your message template—setting delivery, content, and layout preferences—and optionally customize its settings in place.

Notification Profile

Example Test